

Mobile Phones

Green Text with Light Green Background indicates the adapter tip is included with Product.

Red Text with Clear Background indicates the adapter tip is sold separately.

N/A indicates that the adapter is not available or the Product is not compatible.

Apple

| Model | MP1550 | MP1600 | MP1650 | MP1800 | MP2250 |
|--------------------------------|----------|----------|----------|----------|--------|
| iPhone, iPhone 3G, iPhone 3G S | iPod USB | iPod USB | iPod USB | iPod USB | n/a |

Blackberry

| Model | MP1550 | MP1600 | MP1650 | MP1800 | MP2250 |
|--|--------|--------|--------|--------|--------|
| 6210, 6220, 6230, 6280, 6510 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| 7000i, 7100g, 7100i, 7100r, 7100t, 7100v, 7100x, 7105t, 7130c, 7130e, 7130g, 7130v, | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| 7210, 7230, 7250, 7270, 7280, 7290, 7510, 7520 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| 8700c, 8700f, 8700g, 8700r, 8700v, 8703e, 8705g, 8707g, 8707h, 8707v, 8800, 8820, 8830 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| Curve 8300, 8310, 8320, 8330, 8350 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| Pearl 8100, 8100c, 8110, 8120, 8130 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| Bold 9000 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| Bold 9700, Curve 8530, Curve 8900 | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| Pearl 8220, Storm 9530, Storm 2, Tour 9630 | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |

HTC

| Model | MP1550 | MP1600 | MP1650 | MP1800 | MP2250 |
|--|--------|-----------|-----------|-----------|-----------|
| Droid Eris, Droid Incredible, Evo | n/a | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| G1 (with Google) | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| Mogul | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| P3300, P3470, P3600, P4350, P6300, P6500 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| PPC-6700 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| S310, S620, S710, S730 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| Touch, Touch Viva, Tytan II | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| Touch Pro | n/a | HTC Cable | HTC Cable | HTC Cable | HTC Cable |

LG

| Model | MP1550 | MP1600 | MP1650 | MP1800 | MP2250 |
|---|--------|--------|--------|--------|--------|
| AX260, AX275, AX380, AX565, AX8600 | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 |
| AX300, AX830 (Glimmer) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| CE110, CG180 | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 |
| CT810 (Incite) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| CU515, CU575, CU720 Shine, CU915, CU915 Vu, CU920, CU920 Vu-TV | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 |
| LG830 (Spyder) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| LX150, LX160, LX165, LX260, LX570 | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 |
| LX400, LX600 (Lotus) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| UX260, UX380 | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 |
| UX300, UX585 (Rhythm), UX830 (Glimmer) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| VX5400, VX8350, VX8550 (Chocolate 2), VX8600, VX8700, VX8800, VX9400, VX10000 Voyager | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 |
| VX8560 (Chocolate 3), VX8610 (Decoy), VX9100 (enV2), VX9600 (Versa), VX9700 (Dare) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| CHOCOLATE, EnV, Muziq, Rumor, Scoop, Shine, TRAX, WAVE | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 | UA-LG4 |

| Motorola | | | | | |
|---|----------|----------|----------|----------|----------|
| Model | MP1550 | MP1600 | MP1650 | MP1800 | MP2250 |
| A630, A760, A830, A835, A845, A925, A1000 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 |
| A1200, C290, E770 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| BARRAGE, Crush, DEVOUR, DROID, Evoke QA4, Hint QA30, Karma QA1, Quantico, Rival A455 | n/a | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| E815, E816, E1000 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 |
| ic402, ic402 The Blend, ic502 The Buzz, ic602 The Buzz+, ic902 The Deluxe | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| i30sx i50sx i55sr i58sr i60c i85s i88s i90c i95cl i99cl | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 |
| i335 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| i205, i265, i275, i305, i315, i325, i325is, i355, i530, i560, i580, i605, i615, i670, i710, i730, i733, i760, i830, i836, i850, i860, i870, i880, i920, i930 | UA-NEX1 | UA-NEX1 | UA-NEX1 | UA-NEX1 | UA-NEX1 |
| i410, Clutch i465, Brute i680, DEBUT i856, Stature i9 | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| KRZR, KRZR K1, KRZR K1m | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| MOTO Q, MOTO Q9m | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| MOTO Q9, MOTO Q9h, MOTO Q Global, MOTO VE440 | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| MOTOROLA BACKFLIP, CLIQ, CLIQ XT | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| PEBL U6 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| RAZR V3, RAZR V3C, RAZR V3i, RAZR V3m, RAZR V3r, RAZR V3t, RAZR V3xx, RAZR Maxx Ve, RIZR Z3, RIZR Z3tv | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| RAZR2 V8, RAZR2 V9, RAZR2 V9m, ROKR U9 | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| ROKR E1, ROKR E2, ROKR E6, ROKR Z6, ROKR Z6m | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| SLVR L2, SLVR L6, SLVR L7, SLVR L7c | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| V60, V60c, V60g, V60i, V60t, V66, V70, V80, V120, V120C | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 |
| V200, V260, V262, V265, V276, V300, V330, V400, | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 |
| V500, V525, V540, V547, V551, V600, V620, V635, V710, V810 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 |
| V190, V195, V235, V323, V323i, V325, V360, V365, V557 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| W315, W370, W385, W490, W510 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| Entice W766, Z9 | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| Bluetooth Headsets | | | | | |
| H3, H350, H500, H605, H670, H700 | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |
| HS801, HS810, HS820, HS830, HS850 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 | UA-MOTO1 |
| H710 | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| Nokia | | | | | |
| Model | MP1550 | MP1600 | MP1650 | MP1800 | MP2250 |
| E50, E51, E61, E61i, E62, E65, E90 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 |
| E75 | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| N70, N71, N72, N73, N75, N76, N77, N80, N81, N90, N91, N92, N93, N93i, N95 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 |
| N85, N86, N97 | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| N800, N810 Internet Tablet | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 |
| N900 | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| 1100, 1221, 1260, 1261 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 |
| 1650 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 |
| 2116i, 2125i, 2128i, 2220, 2260, 2270, 2280, 2285, 2600, 2610, 2651 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 |
| 2630, 2760, 3109, 3110, 3250, 3500 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 |
| 3100, 3120, 3200, 3205, 3220, 3280, 3285, 3300, 3320, 3360, 3361, 3390, 3395, 3520, 3560, 3570, 3585, 3585i, 3586i, 3587i, 3588i, 3589i, 3590, 3595, 3600, 3620, 3650, 3660 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 |
| 5070, 5200, 5300 XpressMusic, 5500 Sport, 5700 XpressMusic | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 |
| 5100, 5110, 5120, 5125, 5130, 5140, 5160, 5165, 5170, 5170i, 5180, 5180i, 5185, 5185i, 5190, 5192 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 |
| 6010, 6015, 6015i, 6016i, 6019i, 6020, 6030, 6061, 6100, 6110, 6120, 6130, 6150, 6160, 6160i, 6161, 6162, 6168, 6170, 6180, 6185, 6185i, 6190, 6192, 6200, 6225, 6230, 6235, 6235i, 6236, 6236i, 6255i, 6256i, 6310i, 6340, 6340i, 6360, 6370, 6385, 6390 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 |
| 6070, 6080, 6085, 6086, 6101, 6102i, 6103, 6110, 6111, 6120, 6121, 6125, 6126, 6131, 6136, 6151, 6233, 6270, 6280, 6290, 6300, 6301, 6500, 6555 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 |
| 6510, 6560, 6585, 6590, 6590i, 6600, 6610, 6620, 6651, 6670, 6681, 6682, 6800, 6820, 6820i | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 |
| 7110, 7160, 7190, 7210, 7250, 7250i, 7380, 7610 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 |
| 7360, 7370, 7373, 7390, 7500 Prism | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 | UA-NOK2 |
| 8260, 8265, 8265i, 8270, 8290, 8290i, 8310, 8390, 8800, 8801, 8810, 8860, 8890, 9300, 9300i, 9500 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 | UA-NOK1 |
| 6205, 6500 (Classic), 7205 (Intrigue), 7900 (Prism), 8600 (Luna), 8800 (Arte / Sapphire Arte) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |

| Palm | | | | | |
|---|----------|----------|----------|----------|----------|
| Model | MP1550 | MP1600 | MP1650 | MP1800 | MP2250 |
| Centro | UA-PALM2 | UA-PALM2 | UA-PALM2 | UA-PALM2 | UA-PALM2 |
| Palm Pixi, Palm Pixi Plus, Palm Pre, Palm Pre Plus | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| Treo 650, Treo 680, Treo 700p, Treo 700w, Treo 700wx, Treo 750, Treo 755p | UA-PALM2 | UA-PALM2 | UA-PALM2 | UA-PALM2 | UA-PALM2 |
| Treo 800w, Treo Pro | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |

| Samsung | | | | | |
|--|---------|---------|---------|---------|---------|
| Model | MP1550 | MP1600 | MP1650 | MP1800 | MP2250 |
| a117, a127, a137, a167, a177, a226, a227, a237, a257 (Magnet) | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 |
| a303 (Heat), a436, a437, a503, a707, a717, a727 | UA-SAM3 | UA-SAM3 | UA-SAM3 | UA-SAM3 | UA-SAM3 |
| a310, a517, a513 (Fin), a523 (Mysto), a637, a657, a737, a747 (SLM), a767 (Propel), a777, a827 (Access), a837 (Rugby), a867 (Eternity), a877 (Impression), a887 (Solstice) | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 |
| a570, a630, a645, a840, a850, a870, a890, a900, a920, a930, a990 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 |
| a797 (Flight), a897 (Mythic) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| c225, c417, d370, d347, d415 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 |
| d806, d807, d900 (BlackCarbon), e878 | UA-SAM3 | UA-SAM3 | UA-SAM3 | UA-SAM3 | UA-SAM3 |
| e105, e315, e316, e317, e335, e715 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 |
| i220, (Code), i350 (Intrepid), i920 (Omnia II) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| i325 (Ace), i617 (BlackJack II), i627 (Propel Pro), i637 (Jack), i770 (Saga), i907 (Epix), i910 (Omnia) | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 |
| i607 (BlackJack), m610, m620 (UpStage) | UA-SAM3 | UA-SAM3 | UA-SAM3 | UA-SAM3 | UA-SAM3 |
| m220, m240, m320, m330, m540 (Rant), m550 (Exclaim), m560 (Reclaim), m630 (Highnote), m850 (Instinct HD), m900 (Moment) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| m300, m305, m310 (Slash), m340 (Mantra), m510, m520, m800 (Instinct), m810 (Instinct s30) | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 |
| n330, n625, p107, p207 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 |
| r100 (Stunt), r350/r351 (Freeform), r460 (MyShot II), r470 (TwoStep), r560 (Messenger II), r850 (Caliber) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| r200, r210 (Spex), r211, r300, r310 (Byline), r311 (Axle), r410, r420 (Tint), r430 (MyShot), r450 (Messenger), r451C, r500 (Hue), r520 (Trill), r600 (Hue II), r610, r800 (Delve), r810 (Finesse) | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 |
| r225, s307, t309 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 |
| r510, t219, t329, t509, t519 (Trace), t629, t809 | UA-SAM3 | UA-SAM3 | UA-SAM3 | UA-SAM3 | UA-SAM3 |
| t101G, t109, t119, t139, t229, t239, t301G, t339, t349, t401G, t409, t429, t439, t459 (Gravity), t469 (Gravity 2), t539 (Beat), t559 (Comeback), t639, t659, t729 (Blast), t739 (Katalyst), t749 (Highlight), t819, t919 (Behold), t929 (Memoir) | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 |
| t939 (Behold II) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| u310 (Knack), u350 (Smooth), u430, u440 (Gloss), u450 (Intensity), u470 (Juke), u490 (Trance), u640 (Convoy), u650 (Sway) | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 |
| u340, u410, u520, u540, u550, u620 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 |
| u420, u740 | UA-SAM3 | UA-SAM3 | UA-SAM3 | UA-SAM3 | UA-SAM3 |
| u700 (Gleam), u706 (Muse), u750 (Alias 2), u810 (Renown), u900 (FlipShot), u940 (Glyde), u960 (Rogue) | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 |
| v205, v206, x105, x426, x426M, x427, x427M, x475, x495, x496, x497 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 | UA-SAM1 |
| z400 | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 | UA-SAM7 |

| Sanyo | | | | | |
|--|---------|---------|---------|---------|---------|
| Model | MP1550 | MP1600 | MP1650 | MP1800 | MP2250 |
| Katana, Katana II, Katana DLX | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 |
| M1 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 |
| MM-5600, MM-7400, MM-7500, MM-8300, MM-9000 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 |
| PM-8200 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 |
| RL-2000, RL-2500, RL-4920, RL-4930, RL-7300 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 |
| S1 | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| SCP-2400, SCP-3100, SCP-3200 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 |
| SCP-3800 (Katana LX) | UA-U11 | UA-U11 | UA-U11 | UA-U11 | UA-U11 |
| SCP-4900, SCP-4920, SCP-4930 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 |
| SCP-5300, SCP-5400, SCP-5600, SCP-6650 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 |
| SCP-7000, SCP-7050, SCP-7200, SCP-7300, SCP-7400, SCP-7500 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 |
| SCP-8100, SCP-8200, SCP-8300, SCP-8400, SCP-8500, SCP-9000 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 |
| VM-4500 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 | UA-SAN1 |

Sony Ericsson

| Model | MP1550 | MP1600 | MP1650 | MP1800 | MP2250 |
|---|--------|--------|--------|--------|--------|
| C702a, C902, C905 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 |
| F305 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 |
| G700, G705, G705u | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 |
| J100i, J110i, J120i, J220i, J230i | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 |
| K200i, K220i, K310i, K320i, K330, K510i, K530i, K550i, K550im, K610i, K610im, K750i, K770i, K800i, K810i, K850i | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 |
| K700 | UA-SE1 | UA-SE1 | UA-SE1 | UA-SE1 | UA-SE1 |
| M600i | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 |
| P1i, P990i | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 |
| P800, P802, P900 | UA-SE1 | UA-SE1 | UA-SE1 | UA-SE1 | UA-SE1 |
| R380 | UA-SE1 | UA-SE1 | UA-SE1 | UA-SE1 | UA-SE1 |
| S302, S500i | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 |
| S700 | UA-SE1 | UA-SE1 | UA-SE1 | UA-SE1 | UA-SE1 |
| T226, T237, T310, T316, T610, T616, T618, T628, T630, T637 | UA-SE1 | UA-SE1 | UA-SE1 | UA-SE1 | UA-SE1 |
| T250i, T303, T650i, T700 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 |
| V630i, V640i | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 |
| W200a, W200i, W300i, W302, W380i, W580i, W595, W600, W610i, W660i, W700i, W705, W710i, W712a, W800, W810i, W850i, W880i, W900i, W902, W910i, W950i, W960i, W980 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 |
| Z310a, Z310i, Z320i, Z520a, Z525a, Z530i, Z550a, Z610i, Z710i, Z750a | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 | UA-SE2 |
| Z200, Z500, Z600 | UA-SE1 | UA-SE1 | UA-SE1 | UA-SE1 | UA-SE1 |

T-Mobile

| Model | MP1550 | MP1600 | MP1650 | MP1800 | MP2250 |
|------------------|--------|--------|--------|--------|--------|
| G1 (with Google) | UA-U03 | UA-U03 | UA-U03 | UA-U03 | UA-U03 |